

my PMP setup.

Posted by SvoChuck - 17 Mar 2008 01:17

350lb front springs welt front sway bar about in the middle . -3 camber left front . -2 camber right front. 0 toe , max caster. koni shocks just stiffer than halfway.

rear full soft on the konis . 30mm bars 0 toe , -2.5 camber both sides . welt rear sway bar a little more than half stiff .

Thats what I wanted . I did not check it from our last event of 2007 but I'm sure it was close to that.

Tire pressure was really hurting me . I could not adjust to the way the sun was coming in and out of the clouds . so I started the pressures low thinking they would come up then the clouds came out and the tires were rolling over due to low pressure. then in Sundays main race I started the pressures at 35 but after 15 or 20 minutes the rear started feeling slick "Capt Oversteer" I am !

=====